Based on software from "Volker Ziemann, *Hands-on Accelerator physics using MATLAB, CRCPress, 2019*" (https://www.crcpress.com/9781138589940)

Designing the Mobius Ring

Volker Ziemann, 211231, GPLv3

Important: this script uses the 5D beam optics routines, which are assumed to be available in a subdirectory called ./5D which is made accessible with addpath ./5D.

In this script we design the racetrack-shaped Mobius ring from

• V. Ziemann, Beam parameters in a Mobius ring, FREIA Report 2022/01, forthcoming.

which is based on 90° FODO cells. First we define the basic cell in the arcs and in the dispersion suppressor. Then we design the Mobius straight section to adjust the coupling and the straight section to adjust the tunes. Finally we assemble the ring, caluclate the beta functions and tunes, as well as the radiation integrals, based on the new method from

• V. Ziemann, A. Streun, Equilibrium parameters in coupled storage ring lattices and practical applications, forthcoming.

Finally all beam parameters are displayed in a table.

The basic FODO cell

First define the standard 90-degree cell with a length of 2x5 m and two thin-lens quads with a focal length of $f = L/\sqrt{2}$. There are two sector-dipole magnets with a length of 4 m each and deflecting the trajectory by 2 degrees each such that we need a total of 180 full-length dipoles or 90 cells to build a full ring. This also accounts for the 45 cells in one arc. We call the lattice fodo90 and use it as beamline and calculate all transfer matrices with calcmat().

```
L=5; % length of the drift, half-length of cell

F=L/sqrt(2);

fodo90=[
    2,1,0,F;
    1,1,L/10,0;
    4,8,0.5,0.25;
    1,1,L/10,0;
    2,1,0,-F;
    1,1,L/10,0;
    4,8,0.5,0.25;
    1,1,L/10,0;
```


```
];
beamline=fodo90;
[Racc,spos,nmat,nlines]=calcmat(beamline);
```

Now match the tune of the cell to the value specified in the function <code>chisq_tunes()</code> that is defined in the Appendix. First define the start values for the matching, then call <code>fminsearch()</code> to minimize <code>chisq_tunes()</code>, display the transfer matrix <code>Rturn</code> and the tunes <code>Q</code>.

```
Qx = 0.25;
Qy = 0.23;
x0=[3.5,-3.5];
[x,fval]=fminsearch(@chisq_tunes,x0)
x = 1 \times 2
   3.5731 -3.7372
fval = 6.8120e-12
[Racc, spos, nmat, nline] = calcmat(beamline);
Rturn=Racc(:,:,end)
Rturn = 5 \times 5
  -2.3334 16.6749
                      0
0
                                         0.4656
                                  0
  -0.3865
           2.3334
                                         0.0931
                                  0
        0
             0 0.5886 3.3104
                                             0
                 0 -0.3622
                             -0.3379
        0
                                             Ω
                                         1.0000
        0
                 0
                          0
Q=tunes(Rturn)
Q = 1 \times 2
             0.2300
   0.2500
```

Now calculate the periodic beam matrix with unit emittances, which gives us the matrix with the beta functions sigma 0 that we use as starting value for the subsequent plotting routine.

```
sigma0=periodic_beammatrix2(Rturn,1,1,0)
sigma0 = 5x5
  16.6749
            2.3334
                         0
                                  0
                                           0
   2.3334
           0.3865
                        0
                                  0
                                           0
       0
              0
                     3.3368
                             -0.4669
                                           0
        0
                0
                   -0.4669
                             0.3650
                                           0
        0
                0
                                           0
plot_betas(beamline, sigma0)
drawmag(beamline, 1, 2)
dlmwrite('mobius_arc_cell.bl',beamline,'\t')
title('FODO cell with full-length dipoles')
```



```
fodo90m=beamline; % save the matched beamline
```


Dispersion suppressor

Now we calculate the periodic dispersion to later use it as the starting dispersion for the dispersion suppressor.

```
D0=periodic_dispersion(Rturn);
```


The FODO cells in the disperson suppressor have only half-length dipoles and we therefore build a cell fodo_ds to describe it. We only have to change the repeat codes of the drift spaces and dipole segments.

```
fodo_ds=fodo90m; % base teh dispersion supporessor on the matched arc cell
fodo_ds(2,2)=3;
fodo_ds(3,2)=4;
fodo_ds(4,2)=3;
fodo_ds(6,2)=3;
fodo_ds(7,2)=4;
fodo_ds(8,2)=3;
beamline=fodo_ds;
figure; plot_betas(beamline,sigma0)
drawmag(beamline,1,2)
title('Dispersion in the suppressor cell')
```



Now we need to match the quadrupoles in the four quadrupoles in the dispersion suppressor to make the dispersion and its derivartive to zero. The quadrupoles change only by a very small amount.

```
beamline=[ % two cells in the dispersion suppressor
  repmat(fodo_ds,2,1)
  ];
[Racc, spos, nmat, nlines] = calcmat(beamline);
x0=[3.5392,-3.5362];
                             % match dispersion to zero
[x,fval]=fminsearch(@chisq_dispersion,x0)
x = 1 \times 2
   3.5727
          -3.7445
fval = 6.1567e-14
[D,Dp]=calculate_dispersion(beamline,D0);
final_dispersion = [D(end),Dp(end)]
final\_dispersion = 1x2
10^{-6} \times
   0.2402 -0.4659
figure; plot(spos,D,'k','LineWidth',2);
legend('Dispersion D_x')
title('Dispersion suppressor')
drawmag(beamline, 0.5, 0.2)
xlabel('s [m]'); ylabel('D_x [m]')
```



```
dispersion_suppressor=beamline;
Q_ds=tunes(Racc(:,:,end))

Q_ds = 1x2
    0.4996    0.4600

[Racc,spos,nmat,nlines]=calcmat(beamline);
```

Building the arc

Construct the arc of 43 (or 3) cells with adjacent dispersion suppressors, plot the dispersion

```
narc=43 % Number of plain cells in the arc
```


```
beamline=[
  dispersion_suppressor;
  repmat(fodo90m,narc,1);
  dispersion_suppressor
  ];
[Racc,spos,nmat,nlines]=calcmat(beamline);
DD0=[0;0;0;0;1];
[D,Dp]=calculate_dispersion(beamline,DD0);
final_dispersion = [D(end),Dp(end)]
```

```
final_dispersion = 1\times2

10^{-3} X

0.2300 0.0317
```

```
figure; plot(spos,D,'k','LineWidth',2);
legend('Dispersion D_x'); title('Dispersion in one arc')
xlim([min(spos),max(spos)])
xlabel('s [m]'); ylabel('D_x [m]')
```



```
Q=tunes(Racc(:,:,end))


Q = 1x2
     0.7497     0.8071

arc=beamline; % save for posterity
```

Note that the tunes are slightly off, because we used the quads in the diuspersion suppressor to make the dispersions zero, but this slightly (3×10^{-3}) compromised the beta functions and the phase advance.

And now we also plot the beta functions, where we use the matched beta functions for the entire arc sigma_arc. Otherwise we can also use the periodic matric for one cell sigma0.

```
sigma_arc=periodic_beammatrix2(Racc(:,:,end),1,1,0)
sigma_arc = 5x5
  16.6749
             2.3334
                                             0
   2.3334
             0.3865
                           0
                                             0
                                    0
        0
                 0
                      3.3416
                               -0.4676
                                             0
        0
                 0
                     -0.4676
                               0.3647
                                             0
        0
                 0
                           0
                                             0
figure; plot_betas(beamline,sigma_arc); drawmag(beamline,1,2)
```



```
save('sigma_arc.mat','sigma_arc')
```

Mobius straight section

The basic cell

0

0

0

-0.4142

0

18

The two straight sections of the racetrack-shaped ring are based on the following FODO cells with 90° phase advance in both planes.

```
cell90=[
  2,1,0,F;
  1,10,L/10,0;
  2,1,0,-F;
  1,10,L/10,0
];
```

The beta functions and the lattice are shown with the following commands

0.4000

0

```
beamline=cell90;
[Racc, spos, nmat, nline] = calcmat(beamline);
sigma_tuner=periodic_beammatrix2(Racc(:,:,end),1,1,0)
sigma\_tuner = 5x5
  17.0711 2.4142
                          0
                                   0
                                            0
   2.4142
          0.4000
                          0
                                   0
                                            0
                     2.9289
                                            0
        0
                 0
                             -0.4142
```


0

0

```
Q_cell90=tunes(Racc(:,:,end))

Q_cell90 = 1x2
    0.2500    0.2500

figure; plot_betas(beamline,sigma_tuner); drawmag(beamline,1,2)
title('90-degree FDO cell in straight section')
```



```
save('sigma_tuner.mat','sigma_tuner')
```

We will place the skew quadrupoles in the second half of the cell, between the defocussing and the focussing quad of the next section, where β_x is ascending and β_y is descending.

Now we need to find the beta function at the location of the skew quadrupole. To do so, we cyclically shift the lattice by twom positions vertically, such that it starts with the skew quadrupole. Then we calculate the transfer matrices and the periodic beam matrix, which gives us the beta function that we use to set the strength of the skew quad.

```
fodo_from_skew=circshift(fodoskew,2);
beamline=fodo_from_skew;
[Racc,spos,nmat,nline]=calcmat(beamline);
sigma_skew=periodic_beammatrix2(Racc(:,:,end),1,1,0); % betas at skew quad
beta0=sigma_skew(1,1)
```

beta0 = 7.5000

Match arc to skew cell

And now the two cells that match from the arc to the cells with the skew quads.

```
match_arc_to_skew=[cell90;fodoskew];
beamline=match_arc_to_skew;
sigma_start=sigma_arc;
sigma_end=sigma_tuner;
x0=[3.5,-3.5,3.5,-3.5];
[x,fval]=fminsearch(@chisq_betafunctions_skew,x0)
```

```
x = 1x4
3.5572 -3.5649 3.5384 -3.4692
fval = 3.4197e-07
```

```
skew_straight_in=beamline
```

```
skew_straight_in = 10x4
                0
                      3.5573
  2.0000 1.0000
  1.0000
        10.0000 0.5000
                           0
  2.0000 1.0000 0 -3.5649
  1.0000 10.0000 0.5000
                           0
  2.0000 1.0000 0 3.5385
  1.0000 10.0000 0.5000
                       0
                0 -3.4692
  2.0000 1.0000
  1.0000 5.0000 0.5000
                       0
  60.0000 1.0000
                0
                           0
  1.0000 5.0000 0.5000
```

Now this only works reasonably well. The fval is below 10^{-6} .

Match skew to arc cell

In the next step we adjust the four quadrupoles in two cells to match the 90° cells with the skew quadrupoles to the arc cells

```
match_skew_to_arc=repmat(cell90,2,1);
beamline=match_skew_to_arc;
[Racc,spos,nmat,nline]=calcmat(beamline);
```

We use the periodic beta functions in the cells as the starting value sigma 0 and the beta functions in the arc are passed to the fiting routine as the global variable sigma_arc.

```
sigma_start=sigma_tuner;
sigma_end=sigma_arc;
x0=[3.5,-3.5,3.5,-3.5]; %+randn(1,4);
```

```
[x,fval]=fminsearch(@chisq betafunctions skew,x0)
x = 1x4
  3.5267 -3.4723
                  3.5447 -3.5682
fval = 8.5103e-07
skew_straight_out=beamline
skew\_straight\_out = 8x4
  2.0000 1.0000
                   0 3.5267
  1.0000 10.0000 0.5000
                              0
  2.0000 1.0000 0 -3.4724
  1.0000 10.0000 0.5000
                            0
                  0 3.5447
  2.0000 1.0000
  1.0000 10.0000 0.5000
                          0
   2.0000 1.0000
                  0 -3.5682
  1.0000 10.0000 0.5000
```

And now we can define the mobius_straight, but first turn the skew quads on and choose by how much they are turned on to their default value.

```
skew_quads_on=1 % 1=on or 0=off

skew_quads_on = 1

skew_quad_strength=0 % slider to adjust the skew strength

skew_quad_strength = 0
```

It's the focal length and that is inversely proportional to the excitation. Moreover, catch the case when the skew quad is turned off.


```
scale_factor=0;
if abs(skew_quad_strength)>0, scale_factor=1/skew_quad_strength; end
if skew_quads_on
  fodoskew(5,4)=scale_factor*beta0;
  skew_straight_in(9,4)=scale_factor*beta0;
end
```

and now the definition

```
mobius_straight=[
    skew_straight_in;
    fodoskew;
    fodoskew;
    skew_straight_out
];
```

and then propagate sigma_arc through this section

```
beamline=mobius_straight;
[Racc,spos,nmat,nline]=calcmat(beamline);
figure; plot_betas(beamline,sigma_arc); drawmag(beamline,1,2)
title('Mobius straight')
```



```
Rend=Racc(:,:,end)
```

| Rend = 5×5 | | | | |
|---------------------|---------|---------|---------|--------|
| -1.0582 | 0.4166 | 0 | 0 | 0 |
| -0.0097 | -0.9411 | 0 | 0 | 0 |
| 0 | 0 | -1.0226 | -0.1708 | 0 |
| 0 | 0 | 0.0186 | -0.9748 | 0 |
| 0 | 0 | 0 | 0 | 1.0000 |

sigtmp=Rend*sigma_arc*Rend'

| 2.3346 | 0 | 0 | 0 |
|--------|---------|----------------------------------|--|
| 0.3866 | 0 | 0 | 0 |
| 0 | 3.3418 | -0.4675 | 0 |
| 0 | -0.4675 | 0.3647 | 0 |
| 0 | 0 | 0 | 0 |
| | 2.3346 | 2.3346 0 0.3866 0 0 3.3418 | 2.3346 0 0 0.3866 0 0 0 3.3418 -0.4675 |

Bmag=BmagBoth(sigtmp,sigma_arc)

Bmag = 1×2 $10^{-6} \times 0.1110 \quad 0.0081$

Qmobius=tunes(Rend)


Qmobius = 1×2 0.4960 0.5081

Build tuner section of 3 x 2 cells

```
part1=repmat(cell90,2,1); part2=part1; part3=part1;
```

and use the second one part2 as the central part to adjust the tune. Make this a (ϕ_x, ϕ_y) cell

```
beamline=cell90;
Qx=0.2;
Qy = 0.2;
x0=[3.5,-3.5];
[x,fval]=fminsearch(@chisq_tunes_part,x0)
x = 1x2
   4.2532 -4.2532
fval = 6.1873e-12
part2=[beamline;beamline];
[Racc, spos, nmat, nline] = calcmat(beamline);
Rend=Racc(:,:,end)
Rend = 5 \times 5
  -1.5576 15.8779
                         0
                                           0
                     0
          2.1756
  -0.2764
                                  0
                                           0
            0 0.7936 4.1221
0 -0.2764 -0.1756
       0
                                            0
        0
        0
                                       1.0000
                     0
                                  0
Q=tunes(Rend)
Q = 1 \times 2
   0.2000
            0.2000
sigma_part2=periodic_beammatrix2(Rend,1,1,0);
figure; plot_betas(beamline,sigma_part2); drawmag(beamline,1,2)
title(['Part2, Qx = ',num2str(Q(1)),' Qy = ',num2str(Q(2))])
```




and now match the arc to this section

and the reverse section to get from part2 back to the arc

now combine the sections

```
tuner_straight=[
  part1;
  part2;
  part3
  ];
beamline=tuner_straight;
[Racc,spos,nmat,nline]=calcmat(beamline);
figure; plot_betas(beamline,sigma_arc); drawmag(beamline,1,2)
title('Tune straight')
```



```
Rend=Racc(:,:,end); Q=tunes(Rend)

Q = 1x2
    0.4171    0.4061

sigma=Rend*sigma_arc*Rend';
Bmag=BmagBoth(sigma,sigma_arc)

Bmag = 1x2
10<sup>-8</sup> x
    0.0328    0.1122
```

Now define the ring and fix the tune

```
ring=[
  mobius_straight;
  arc;
  tuner_straight;
```

```
arc
];
ring2=[
  tuner_straight;
  arc;
  mobius_straight;
  arc
];
beamline=ring;
[Racc,spos,nmat,nlines]=calcmat(beamline); Rend=Racc(:,:,end);
Q=tunes(Rend)
```


```
Q = 1 \times 2
0.4126
0.5283
```


Plot betafunctions


```
flipped=0;
show=1
```

show = 1

[beta1,beta2,disp,Qtune]=plot_betas_unrolled(beamline,flipped,show);







```
Qtunes=Qtune(end,:)

Qtunes = 1x2
    26.4126    24.5283
```


Slice the elements and calculate the radiation integrals

```
beamline=dipole_slicer(beamline,100);
[I1,I2,I3,I4,I5]=radiation_integrals(beamline,flipped);
```

Then use the integrals to calculate the momentum compaction factor α , the momentum spread σ_p , the three damping times τ_x , τ_y , τ_p , and the eigenemittances ε_1 and ε_2 .

Then calculate the periodic beammatrix σ_0 for the emittances just calculated and display the beam sizes.

```
[Racc,spos,nmat,nlines]=calcmat(beamline); Rend=Racc(:,:,end);
sigma0=periodic_beammatrix2(Rend,eps(1),eps(2),sigp);
figure; plot_sigmamatrix(beamline,sigma0);
```



Finally display all parameters

0

0

0

0

0.0645

0

-0.9014

```
[Racc, spos, nmat, nlines, ibl] = calcmat(beamline);
Rturn=Racc(:,:,end)
Rturn = 5 \times 5
   -2.0707
             8.7001
                                           0.0003
                            0
                                      0
                           0
   -0.2017
             0.3646
                                      0
                                           0.0000
        0
                  0
                      -1.0670
                                -0.5913
```

1.0000

```
[O,A,T,p]=sagrub(Rturn,flipped);
figure
box on
text(0.05,0.9,['E_0 = ',num2str(E0/1e3),' GeV C = ',num2str(C), 'm'],'FontSize',16)
text(0.05, 0.8, ['Q_a = ',num2str(Qtune(end,1),5),' Q_b = ',num2str(Qtune(end,2),5)],'For example 1.5 text(0.05,0.8, ['Q_a = ',num2str(Qtune(end,1),5),' Q_b = ',num2str(Qtune(end,2),5)],'For example 2.5 text(0.05,0.8, ['Q_a = ',num2str(Qtune(end,1),5),' Q_b = ',num2str(Qtune(end,2),5)],'For example 2.5 text(0.05,0.8, ['Q_a = ',num2str(Qtune(end,2),5)],' For example 2.5 text(0.05,0.8, ['Q_a = ',num2str(Qtune(e
text(0.05, 0.7, ['eps_a = ', num2str(eps(1), 3), 'eps_b = ', num2str(eps(2), 3)], 'FontSize'
text(0.05, 0.6, ['tau_a = ',num2str(tau(1)*1e3,3), 'ms tau_b = ',num2str(tau(2)*1e3,3), 'ms tau_b = ',num2str(tau(2)*1e3
                                                                                                                                                                                                                                                                                                                          sig_p = ',num2str(sigp,'%.2e')]
text(0.05,0.5,['tau_e = ',num2str(tau(3)*1e3,3),' ms
text(0.05,0.4,['alpha = ',num2str(alpha,'%.2e')],'FontSize',16)
text(0.05,0.3,['I_1 = ',num2str(I1),' I_2 = ',num2str(I2),' I_3 = ',num2str(I3)],'I_3 = ',num2str(I3)]
text(0.05,0.2,['I_{4a}] = ',num2str(I_{4(1),3}),'
                                                                                                                                                                                                                                                                            I_{4b} = ',num2str(I4(2),3)],'FontSize
text(0.05, 0.1, ['I_{5a}] = ', num2str(I5(1), 3), 'I_{5b}] = ', num2str(I5(2), 3)], 'FontSize'
title('Beam parameters')
axis off
```

Beam parameters

$$E_0 = 10 \text{ GeV} \quad C = 1060 \text{m}$$
 $Q_a = 26.413 \quad Q_b = 24.528$
 $eps_a = 1.86e-08 \quad eps_b = 0$
 $tau_a = 9.19 \text{ ms} \quad tau_b = 9.17 \text{ ms}$
 $tau_e = 4.58 \text{ ms} \quad sig_p = 7.99e-04$
 $alpha = 1.88e-03$
 $I_1 = 1.998 \quad I_2 = 0.05476 \quad I_3 = 0.00047787$
 $I_{4a} = 0.000152 \quad I_{4b} = 0$
 $I_{5a} = 6.92e-06 \quad I_{5b} = 0$

Now save the world

```
save('MR0_beamline.mat','beamline','E0','C','beta0','flipped')
toc
```

Elapsed time is 19.318293 seconds.

Appendix

chisq_tunes()

The function chisq_tunes() is used when matching the tunes of the FODO cell. It receives the focal lengths of the two quadrupoles in the array x as input and returns the squared difference to the desired tune values, which are passed as global variables Qx and Qy to this function.

chisq_dispersion()

The function <code>chisq_dispersion()</code> receives the focal lengths of the quadrupoles in the dispersions suppressor in the array x as input and returns the squared difference of the horizontal dispersion as <code>chisq</code>.

chisq_betafunctions_skew()

The function $chisq_betafunction_skew()$ is used to match the Mobius and the tuner straight section to the arcs. It receives the focal lengths of the quadrupoles in the two matching cells adjacent to the arc in the array x as input and returns the squared difference of the mismatch parameter Bmaq() as chisq.

```
function chisq=chisq betafunctions skew(x)
global beamline sigma0 D0
                               % need info about the beamline
global sigma_start sigma_end
betax=sigma_end(1,1); alfax=-sigma_end(1,2);
betay=sigma_end(3,3); alfay=-sigma_end(3,4);
beamline(1,4)=x(1); % change quadrupole excitations
beamline(3,4)=x(2);
beamline(5,4)=x(3);
beamline(7,4)=x(4);
[Racc,spos,nmat,nlines]=calcmat(beamline); Rend=Racc(:,:,end);
sigma=Rend*sigma_start*Rend';
% chisq=(sigma(1,1)-betax)^2+(sigma(1,2)+alfax)^2 ...
+(sigma(3,3)-betay)^2+(sigma(3,4)+alfay)^2;
chisq=Bmags(sigma_end(1:2,1:2),sigma(1:2,1:2)) ...
  +Bmags(sigma end(3:4,3:4),sigma(3:4,3:4))-2;
end
```

Bmags()

The function Bmags() receives two 2×2 beam matrices sig1 and sig2 as input and returns the mismatch parameter Bmag, which is defined in Equation 8.15 in [V. Ziemann, $Hands-on\ accelerator\ physics...$].

```
function out=Bmags(sig1,sig2)
eps1=sqrt(det(sig1)); beta1=sig1(1,1)/eps1; alpha1=-sig1(1,2)/eps1;
eps2=sqrt(det(sig2)); beta2=sig2(1,1)/eps2; alpha2=-sig2(1,2)/eps2;
out=0.5*(beta1/beta2+beta2/beta1+beta1*beta2*(alpha1/beta1-alpha2/beta2)^2);
end
```

BmagBoth()

The function BmagBoth() receives two 4×4 beam matrices as input and returns the sum of the horizontal Bmags and the vertical Bmags, with unity subtracted such that the matched beams return zero.

```
function Bmag=BmagBoth(sig1,sig2)
Bmag=[Bmags(sig1(1:2,1:2),sig2(1:2,1:2))-1, ...
Bmags(sig1(3:4,3:4),sig2(3:4,3:4))-1];
end
```

chisq_tunes_part()

The function chisq_tunes_part() is used to match the tunes of the central cells in the tuner straight. It receives the focal lengths of the quadrupoles in the array x as input and returns the squared difference to the desired tune values, which are passed as global variables Qx and Qy to this function.